

Manufacturer	Alfa Romeo	Model	Brera	Year	2005
Wire	Wire Color	Polarity	Location		
12V	Red	+	Front of Fuse Box		
Starter	RED		24 Pins Black/Violet Connector over the Clutch pedal, at Central Control Unit		
Ignition	Orange	+	Brown 20 pins connector front of fuse box, pin number 14		
Ignition 2	RED		pin 32 in 32 pins black-violet connector front of fuse box		
Power Lock	Use CAN				
Power Unlock	Use CAN				
Parking Lights + Parking Lights - Hazard Lights			*		
Door Contact	<u>GREEN-BLACK</u>	-	pin 21 of 40 pins black connector at front of fuse box		
Trunk Pin	BLUE-BLACK	-	pin 36 of 40 pins black connector at front of fuse box		
Trunk/Hatch Release					
Fuel Pump					

* FRONT LEFT LIGHT BLUE AT PIN 38 OF 40 WAY BLUE CONNECTOR AT FRONT OF FUSE BOX. LEFT REPEATER LIGHT BLUE WHITE PIN 2 OF 40 WAY BLUE CONNECTOR AT FRONT OF FUSE BOX. REAR LEFT LIGHT BLUE PIN 12 OF 40 WAY BLUE CONNECTOR AT FRONT OF FUSE BOX. FRONT RIGHT LIGHT BLUE-RED PIN 39 OF 40 WAY BLUE CONNECTOR. RIGHT REPEATER LIGHT BLUE-BLACK PIN 22 OF 40 WAY BLUE CONNECTOR AT FRONT OF FUSE BOX. REAR RIGHT LIGHT BLUE-BLACK PIN 3 OF 40 WAY BLUE CONNECTOR AT FRONT OF FUSE BOX.